
# **Troubleshooting Guide**



## 1. METER INSTALLATION

A. Check that meters are installed in the correct orientation to the water flow.


B. If meters are installed vertically, confirm that a Non-Return-Valve (NRV) is installed after the submeter



#### 2. METER POWER

Check that there is power to the meter. When plugged in, the bulb will illuminate for 10 seconds.

Unplug and plug in the meter to check for the blue light. It is okay if the flash is dull, meter is still functional




#### Blue light flashes when plugged in.

### 3. ROUTER POWER & WIFI

Check that the router is plugged in and showing the correct lights. WiFi light and 4G light should be solid. The globe light should be flashing. Antennas should be adjusted to different positions as shown.

If the lights do not look like the example to the right, please unplug the router, wait 10-15 seconds, and plug back in. Wait roughly 1 minute for all the lights to come back on. If they come back on, problem has been resolved, if they do not, please notify True Submeter.

To confirm that router was not reset to factory settings, please confirm on a mobile device that "TrueSubmeter" shows up as a WiFi option.



STILL HAVING PROBLEMS? PLEASE CONTACT OUR SUPPORT TEAM AT SUPPORT@TRUESUBMETER.COM OR CALL 612-433-2239.

612-433-2239

15105 Minnetonka Ind. Rd. STE 222 Minnetonka, MN 55345

SALES@TRUESUBMETER.COM

